

- Remove all dust, debris, dirt and standing water from the hole to be filled (for a permanent repair please ensure the hole is dry), **there is no need to cut back !**



- Pour pot hole mix into the clean hole and smooth over using a flat edged tool, ideally a trowel.



- Open bucket containing 5.5 kgs of resin base material – **Part A** (this contains prepigmented resin, filler & fine quartz). Mix thoroughly.
- Add hardener bags **Part B** (as detailed over page) and mix thoroughly
- Add the 15 kg of quartz mix Part C (hard wearing natural quartz) and mix thoroughly.



- Finish off with a flat edged tool to ensure the surface is smooth.



- Scatter fully with bauxite (**Part D**) ensuring all resin has been completely covered (option - lightly roll to embed the bauxite).



- Allow to fully cure, then sweep away any excess bauxite



Resins	+5°C - +20°C	+20°C - +35°C
Resideck Part B Hardener	3 x 100g Part B hardener packs	2 x 100g Part B hardener packs



WARRANTY

If the Resideck Permanent Pot Hole repair does not stay put for 5 years we will replace the kit free of charge.

See details for full terms and conditions of the warranty